How to Set Feature Code to Enable/Disable DND/Call Forward Service

In the newest firmware version (V3.5.7.2) of VigorIPPBX router, a new function is supported to allow you to set feature codes to enable or disable DND and Call Forward functions.

1. Log into the web user interface.

2. Open **IPPBX>>PBX System** and click the **PBX Service Number** link. The following web page will appear. Note the items of Turn ON/OFF Call Forward and Turn ON/OFF DND. The system will offer default settings for your reference.



3. Click **OK** to save the settings.

According to the above configuration, you can

Enable/Disable DND	Use your extension to dial ＊78 (default setting, also is the feature code of enabling DND function). VigorIPPBX will treat it as an extension with DND. All the callers of incoming calls to reach such extension will hear busy tone. To disable DND, simply use the same extension to dial ＊79 (a feature code of disabling DND function).
Enable/Disable Call Forward	Use your extension to dial ＊72(default setting, also is the

	feature code of enabling Call Forward function)+the extension number (e.g., 510) you want to transfer. VigorIPPBX will transfer all the incoming calls that want to reach such extension to the specified extension (e.g., 510). For example, you want to transfer all the incoming calls to the extension 501. After finished the above web page, you can use your extension to dial ＊72501. To disable Call Forward, simply use the same extension to dial ＊73 (a feature code of disabling Call Forward function).